

■ Instructions for use

BIONANO SCAN PERMANENT e WASHABLE

- ① Shake well before use.
- ② Apply uniformly to the surface to be scanned using a brush.
- ③ Scan the applied surface.
- ④ After checking the results of the scan, remove the applied NANO SCAN **with acetone and steam**.
Only steam is needed for washable.
SCANPLUS+SOLUTION is a rehydration additive to help thin the regular NANO SCAN
- ① Using the dropper.
- ② Add appropriate amount to the NANO SCAN .
- ③ After closing the lid of the NANO SCAN , shake it for about 5 seconds to mix the product well.

■ Storage

After using the product, close the lid tightly.

Avoid direct sunlight, moisture and heat sources and store in a dry place between 5-25°C (41-77°F).

■ Warnings

The user should observe the usage methods and precautions.

Do not use for any purpose other than the intended use of this and a mask while using the product. If it gets into the user's eyes, wash it with running water and consult a doctor.

If it gets soap and running water.

Do not let children and the elderly handle the product.

In addition, if the user of the product has inf reaction) or other allergic reactions or has a headache, feels dizziness, and/or other symptoms caused by inhalation, stop us consult a doctor.

Be careful not to mix with foreign substances. Avoid direct sunlight and do not use near open flames.